

STRIKE **ARRAY** 2

DMX Chart



TABLE OF CONTENTS

DMX Channel Assignments and Values 1

- 9 Ch..... 1
- 8 Ch..... 2
- 5 Ch..... 2
- 4 Ch..... 3
- 3 Ch..... 3
- 2 Ch..... 3
- 1 Ch..... 3

Contact Us 4

DMX Channel Assignments and Values

9 Ch

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	White 1	000 ⇔ 255	0–100%
4	Amber 1	000 ⇔ 255	0–100%
5	White 2	000 ⇔ 255	0–100%
6	Amber 2	000 ⇔ 255	0–100%
7	Strobe	000 ⇔ 010	No function
		011 ⇔ 132	Strobe, slow to fast (all pods)
		133 ⇔ 255	Strobe, slow to fast (random strobe macros)
8	Auto Programs	000 ⇔ 010	No function
		011 ⇔ 040	Auto 1 (slow to fast)
		041 ⇔ 080	Auto 2 (slow to fast)
		081 ⇔ 120	Auto 3 (slow to fast)
		121 ⇔ 160	Auto 4 (slow to fast)
		161 ⇔ 200	Auto 5 (slow to fast)
		201 ⇔ 240	Auto 6 (slow to fast)
241 ⇔ 255	No function		
9	Dimmer Speed Mode*	000 ⇔ 051	Current dimmer speed mode
		052 ⇔ 101	Dimmer speed mode off (linear dimmer)
		102 ⇔ 152	Dimmer speed mode 1 (fastest)
		153 ⇔ 203	Dimmer speed mode 2
		204 ⇔ 255	Dimmer speed mode 3 (slowest)



***Hold desired dimmer speed value for 3 seconds, then release. This changes the dimmer speed setting in the menu.**

DMX CHART



V1.3.0

8 Ch

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red Shift	000	On
		001 ⇔ 255	Off
4	Strobe	000 ⇔ 010	No function
		011 ⇔ 132	Strobe, slow to fast (all pods)
		133 ⇔ 255	Strobe, slow to fast (random strobe macros)
5	White 1	000 ⇔ 255	0–100%
6	White 2	000 ⇔ 255	0–100%
7	Auto Programs	000 ⇔ 010	No function
		011 ⇔ 040	Auto 1 (slow to fast)
		041 ⇔ 080	Auto 2 (slow to fast)
		081 ⇔ 120	Auto 3 (slow to fast)
		121 ⇔ 160	Auto 4 (slow to fast)
		161 ⇔ 200	Auto 5 (slow to fast)
		201 ⇔ 240	Auto 6 (slow to fast)
		241 ⇔ 255	No function
8	Dimmer Speed Mode*	000 ⇔ 051	Current dimmer speed mode
		052 ⇔ 101	Dimmer speed mode off (linear dimmer)
		102 ⇔ 152	Dimmer speed mode 1 (fastest)
		153 ⇔ 203	Dimmer speed mode 2
		204 ⇔ 255	Dimmer speed mode 3 (slowest)

5 Ch

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Red Shift	000	On
		001 ⇔ 255	Off
3	Strobe	000 ⇔ 010	No function
		011 ⇔ 255	Strobe, slow to fast
4	Auto Program	000 ⇔ 010	No function
		011 ⇔ 040	Auto 1 (slow to fast)
		041 ⇔ 080	Auto 2 (slow to fast)
		081 ⇔ 120	Auto 3 (slow to fast)
		121 ⇔ 160	Auto 4 (slow to fast)
		161 ⇔ 200	Auto 5 (slow to fast)
		201 ⇔ 240	Auto 6 (slow to fast)
		241 ⇔ 255	No function
5	Dimmer Speed*	000 ⇔ 051	Current dimmer speed mode
		052 ⇔ 101	Dimmer speed mode off (linear dimmer)
		102 ⇔ 152	Dimmer speed mode 1 (fastest)
		153 ⇔ 203	Dimmer speed mode 2
		204 ⇔ 255	Dimmer speed mode 3 (slowest)



***Hold desired dimmer speed value for 3 seconds, then release. This changes the dimmer speed setting in the menu.**

4 Ch

Channel	Function	Value	Percent/Setting
1	White 1	000 ⇔ 255	0–100%
2	White 2	000 ⇔ 255	0–100%
3	Red Shift	000 001 ⇔ 255	On Off
4	Dimmer Speed*	000 ⇔ 051 052 ⇔ 101 102 ⇔ 152 153 ⇔ 203 204 ⇔ 255	Current dimmer speed mode Dimmer speed mode off (linear dimmer) Dimmer speed mode 1 (fastest) Dimmer speed mode 2 Dimmer speed mode 3 (slowest)

3 Ch

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Red Shift	000 001 ⇔ 255	On Off
3	Dimmer Speed*	000 ⇔ 051 052 ⇔ 101 102 ⇔ 152 153 ⇔ 203 204 ⇔ 255	Current dimmer speed mode Dimmer speed mode off (linear dimmer) Dimmer speed mode 1 (fastest) Dimmer speed mode 2 Dimmer speed mode 3 (slowest)



***Hold desired dimmer speed value for 3 seconds, then release. This changes the dimmer speed setting in the menu.**

2 Ch

Channel	Function	Value	Percent/Setting
1	White 1	000 ⇔ 255	0–100%
2	White 2	000 ⇔ 255	0–100%

1 Ch

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%

Contact Us

General Information	Technical Support
Chauvet World Headquarters	
Address: 3360 Davie Rd., Suite 509 Davie, FL 33314 Voice: (954) 577-4455 Fax: (954) 929-5560 Toll Free: (800) 762-1084	Voice: (844) 393-7575 Fax: (954) 756-8015 Email: chauvetcs@chauvetlighting.com Website: www.chauvetprofessional.com
Chauvet U.K.	
Address: Pod 1 EVO Park Little Oak Drive, Sherwood Park Nottinghamshire, NG15 0EB UK Voice: +44 (0) 1773 511115 Fax: +44 (0) 1773 511110	Email: UKtech@chauvetlighting.eu Website: www.chauvetprofessional.eu
Chauvet Benelux	
Address: Vaartlaan 9 9800 Deinze Belgium Voice: +32 9 388 93 97	Email: BNLtech@chauvetlighting.eu Website: www.chauvetprofessional.eu
Chauvet France	
Address: 3, Rue Ampère 91380 Chilly-Mazarin France Voice: +33 1 78 85 33 59	Email: FRtech@chauvetlighting.fr Website: www.chauvetprofessional.eu
Chauvet Germany	
Address: Bruno-Bürgel-Str. 11 28759 Bremen Germany Voice: +49 421 62 60 20	Email: DEtech@chauvetlighting.de Website: www.chauvetprofessional.eu
Chauvet Mexico	
Address: Av. de las Partidas 34 - 3B (Entrance by Calle 2) Zona Industrial Lerma Lerma, Edo. de México, CP 52000 Voice: +52 (728) 690-2010	Email: servicio@chauvet.com.mx Website: www.chauvetprofessional.mx

Visit the applicable website above to verify our contact information and instructions to request support. Outside the U.S., U. K., Ireland, Mexico, France, Germany, or Benelux, contact the dealer of record.



RoHS

